

ADA MOTOR LTD	KOL YATAK	LISTER / PETTER
----------------------	------------------	------------------------

TANIM	MOTOR TİPİ	BOYUT	ADA MOTOR NR.	REFERANS NR.
KOL YATAK	LR / LD / SL	STD 0.25 0.50 0.75 1.00	47 4801 47 4802 47 4803 47 4801-030 47 4801-040	570-12180
KOL YATAK	LT / LV	STD 0.25 0.50 0.75 1.00	47 4804 47 4805 47 4806 47 4804-030 47 4804-040	601-50420
KOL YATAK	LPW	STD 0.25 0.50 0.75 1.00	47 4800 47 4800-010 47 4800-020 47 4800-030 47 4800-040	750-11260
KOL YATAK	SR / SW	STD 0.25 0.50 0.75 1.00	47 4807 47 4808 47 4809 47 4807-030 47 4807-040	570-12170
CON-ROD BEARING	ST / STW	STD 0.25 0.50 0.75 1.00	47 4810 47 4811 47 4812 47 4810-030 47 4810-040	570-12980
KOL YATAK	TS / TR / TL	STD 0.25 0.50 0.75 1.00	47 4813 47 4814 47 4815 47 4813-030 47 4813-040	570-31370

ADA MOTOR LTD	KOL YATAK	LISTER / PETTER
----------------------	------------------	------------------------

TANIM	MOTOR TİPİ	BOYUT	ADA MOTOR NR.	REFERANS NR.
KOL YATAK	TX	STD 0.25 0.50 0.75 1.00	47 4816 47 4816-010 47 4816-020 47 4816-030 47 4816-040	570-36150
KOL YATAK	HA / HB / HW	STD 0.25 0.50 0.75 1.00	47 4817 47 4818 47 4819 47 4817-030 47 4817-040	572-11940
KOL YATAK	HR / HRS / HRW / HRWS / HL / HLT	STD 0.25 0.50 0.75 1.00	47 4820 47 4821 47 4822 47 4820-030 47 4820-040	572-50650
KOL YATAK	AV1 / AV2	STD 0.25 0.50	47 6503 47 6504 47 6505	393000 393003 393004
KOL YATAK	PH / PHW / PJ / PJW	STD 0.25 0.50	47 6507 47 6508 47 6509	392989 392990 392991